

CROWDFLEX ASSEMBLY INSTRUCTIONS

Use two people to lift and assemble your new acrylic barricade, and in a few minutes, it will be ready for years of service.

“STARTER” PARTS:

- Two 1” x 1” x 28” horizontal legs with rubber stoppers
- Four eyelet screws
- Four bolts
- Four lock washers
- One allen wrench

“EXTENSION” PARTS:

- One 1” x 1” x 28” horizontal leg with rubber stoppers
- Two eyelet screws
- Two hooks
- Two lock washers
- Two bolts
- Two screws
- One allen wrench

Starter Assembly Instructions

STEP 1: Attach the legs at a perpendicular angle to the bottom of the starter unit by inserting bolts into the two holes in the bottom of the panel. Then tighten with the provided allen wrench.

STEP 2: Lift the panel from the assembly surface and lower it to the floor upright at a true 90° angle. Position it in your facility as desired.

Extension Assembly Instructions

STEP 1: Attach one leg by repeating “Step 1” of the starter unit.

STEP 2: On the side opposite the leg, line up the hooks to each set of holes in the top and bottom of the panel. Insert the screws in the holes and tighten with a flathead screwdriver.

STEP 3: Insert the “eyelets” into the four holes of the starter unit and tighten by hand. Make sure eyelet is parallel to the ground.

STEP 4: Connect the panels by lifting the hook into the eyelets. And position the full barricade to the desired angle.