



Hardware included:



Screws



Step One:

Layout poles in correct shape and screw in bolts to connect the poles together with the screws provided.

Step Two:

Screw in wheels to the bottom of frame.

Step Three:

Add the canvas exterior using velcro attachments around poles.

Step Four:

Screw in the wheels to the bottom of the panel.

